

Grid Connect Photovoltaic Inverter
KP□□G-OD-□□
KP□□L-OD-□□

Communication Manual

OMRON

Introduction

Thank you for choosing the KP□□G or KP□□L Grid Connect Photovoltaic Inverter (hereafter called KP inverter). This communication manual describes essential information regarding communication of the KP inverter.

The KP inverter is designed for use in Grid Connect Solar Systems. The installation must be always carried out by qualified personnel with knowledge of electrical systems and according to national standards for electrical installations.

- This communication manual is intended for Users and Installers of the KP inverter.
- Read this manual carefully and make sure that you understand it well to ensure that you are using the communication of KP inverter.
- Keep this manual in a safe location near the equipment so that it is available for reference when required.
- For detail description such as function, performance, and usage of the KP inverter, refer to the manual of the KP inverter.

Read and Understand This Manual

Read and understand this manual before using the KP inverter. Please consult your OMRON representative if you have any questions or comments.

Warranty and Limitations of Liability

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for specified period from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

Application Considerations

SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this manual.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Disclaimers

PERFORMANCE DATA

Performance data given in this manual is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons. Consult with your OMRON representative at any time to confirm actual specifications of purchased product.

DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

ERRORS AND OMISSIONS

The information in this manual has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

COPYRIGHT AND COPY PERMISSION

This document shall not be copied for sales or promotions without permission.

This document is protected by copyright and is intended solely for use in conjunction with the product. Please notify us before copying or reproducing this document in any manner, for any other purpose. If copying or transmitting this document to another, please copy or transmit it in its entirety.

Contents

Introduction.....	1
Read and Understand This Manual.....	2
Chapter 1 Settings	1-1
1-1 Outline of communication functions	1-2
1-2 Cable Connections	1-2
1-3 Communication settings.....	1-3
1-3-1 Communication settings for KP40G	1-3
1-3-2 Communication settings for KPool	1-4
Chapter 2 CompoWay/F	2-1
2-1 CompoWay/F Communication Specifications	2-2
2-2 Frame Formats.....	2-3
2-2-1 Command Frame Structure	2-4
2-2-2 Response Frame Structure	2-5
2-3 FINS-mini.....	2-6
2-3-1 PDU Formats.....	2-6
2-3-2 Variable Areas	2-6
2-3-3 Type code (variable type)	2-7
2-3-4 Address	2-7
2-3-5 Number of elements	2-7
2-3-6 List of Services	2-7
2-4 Detailed Description of Services.....	2-8
2-4-1 Read from variable area	2-8
2-4-2 Composite read from variable area (KPool only)	2-11
2-4-3 Read Controller information	2-13
2-4-4 Read Controller Attributes	2-14
2-4-5 Read Controller Status	2-15
2-4-6 Echoback Test.....	2-18
2-4-7 Operation Command.....	2-19
2-4-8 Read character string area.....	2-21
2-5 Response Code List	2-22
Chapter 3 Modbus	3-1
3-1 Modbus Communication Specifications	3-2
3-2 Frame Formats.....	3-3
3-2-1 Command Frame Structure	3-3
3-2-2 Response Frame Structure	3-5
3-3 Function Codes	3-6
3-4 Variable Areas	3-7
3-4-1 Addresses	3-7
3-4-2 Number of Elements.....	3-7
3-4-3 Communications Data	3-7
3-5 Detailed Description of Services.....	3-8
3-5-1 Multiple Read from Variable Area.....	3-8

3-5-2 Single Write to Variable Area 3-9

Chapter 4 Communications Data 4-1

4-1 Variable Area (Setting Range) List..... 4-2



Settings

This section describes the settings of communications by the KP inverter.

1-1	Outline of communication functions	1-2
1-2	Cable Connections	1-2
1-3	Communication settings	1-3
1-3-1	Communication settings for KP40G	1-3
1-3-2	Communication settings for KPool	1-4

1-1 Outline of communication functions

The KP inverter is equipped with an RS232C/RS-485 port, which allows remote monitoring and remote operations over networks.

The following protocol is supported:

Model	Supported protocol
KP40G	CompoWay/F
KP□□L	CompoWay/F, Modbus

The KP inverter has the following communication functions:

Reading settings and data

Executing operation commands

CompoWay/F is OMRON's unified communications protocol for general-purpose serial communications. This unified format has a proven track record with OMRON Programmable Controllers, has FINS-compliant commands (see note), and simplifies communications between the host computer and components.

Note:

FINS (Factory Interface Network Service) is a messaging protocol for communications between Controllers in OMRON FA networks.

Modbus is a standard communications control method that conforms to the Modicon Company's RTU-mode Modbus Protocol (PI-MBUS-300 Revision J).

Support functions are similar to the CompoWay/F Read Variable Area, Write Variable Area, Operation Command.

1-2 Cable Connections

Refer to the manual of each inverter for cable connections.

1-3 Communication settings

1-3-1 Communication settings for KP40G


Communication protocol settings

You can use only CompoWay/F on KP40G.

There is no setting for communication protocol.

Node number (Unit number) settings

Node number can be set by setting switch as shown in the figure.





Baud rate settings

Baud rate is fixed 19200bps.

1-3-2 Communication settings for KP□□L

Communication protocol settings

Select CompoWay/F or Modbus on KP□□L by LCD menu.



Node number (Unit number) and baud rate settings

Select communication protocol and set node number and baud rate by LCD menu.

[Setting procedure]

- 1** Press the MODE key for 5 seconds, and enter Mode Selection Display.
- 2** Use <</>> to select "Setup".
- 3** Press the ENT key and enter mode of User's setup.

<Protocol>

- 4** Select "Setup:Protocol" and press the ENT key.
- 5** Use <</>> to change protocol. If you select "Auto", protocol is detected automatically according to communication command.

<Node number>

- 4** Select "Setup:COM_Unit" and press the ENT key.
- 5** Use <</>> to change number.

<Baud rate>

4 Select "Setup: COM_232C" or "Setup: COM_485", and press the ENT key.

5 Use <</> to change baud rate.

6 Press the MODE key to confirm communication protocol.

7 Press the MODE key to rerun normal display.

Refer to the user's manual of KP□□L for more detail information.

2

CompoWay/F

This section describes how to use CompoWay/F communications based on communication commands.

2-1	CompoWay/F Communication Specifications	2-2
2-2	Frame Formats	2-3
2-2-1	Command Frame Structure	2-4
2-2-2	Response Frame Structure	2-5
2-3	FINS-mini	2-6
2-3-1	PDU Formats	2-6
2-3-2	Variable Areas	2-6
2-3-3	Type code (variable type)	2-7
2-3-4	Address	2-7
2-3-5	Number of elements	2-7
2-3-6	List of Services	2-7
2-4	Detailed Description of Services	2-8
2-4-1	Read from variable area	2-8
2-4-2	Composite read from variable area (KPool only)	2-11
2-4-3	Read Controller information	2-13
2-4-4	Read Controller Attributes	2-14
2-4-5	Read Controller Status	2-15
2-4-6	Echoback Test	2-18
2-4-7	Operation Command	2-19
2-4-8	Read character string area	2-21
2-5	Response Code List	2-22

2-1 CompoWay/F Communication Specifications

Communications Control Method


Programs can be created in the host computer (e.g., a personal computer) to set or monitor parameters in the KP inverter. Therefore the descriptions in this section are from the standpoint of the host computer. For example, "Read/Write" is referred as the host computer reading or writing to the inverter.

Communication Specifications


Interface	RS-485	RS-232C
Transmission path connections	Multipoint	Single point
Communications	2-wire system half duplex	Half duplex
Synchronization	Start-stop synchronization	
Baud rate *: default	KP40G 19200bps KP□□L 4800 / 9600 / *19200bps	KP40G 9600bps KP□□L 4800 / *9600 / 19200bps
Transmitted code	ASCII	
Data bit length	7 bits	
Stop bit length	2 bits	
Error detection	Vertical parity (even) BCC (block check character)	
Data transmission	LSB first	
Flow control	None	
Retry function	None	
Communication buffer	KP40G / KP□□L 280 reception buffer bytes 273 transmission buffer bytes	
Response wait time after RS-485 command transmitted (Prohibit time from when command is sent from host to when response is sent from inverter.)	KP40G : 0.5 ms or more KP□□L : 3 to 99 ms (adjustable)	
Waiting time after RS-485 response (Prohibit time for command transmission after response received from inverter)	5.0 ms or more	
The next command waiting time after simultaneous broadcasting	30ms or more	

2-2 Frame Formats

The host computer sends a command frame, and the KP inverter sends a response frame based on the content of the command frame. One response frame is sent in response to one command frame.



After a receiving a response from the inverter, have the host computer wait specified waiting time at least before sending the next command as shown in the figure.




2-2-1 Command Frame Structure

Based on CompoWay/F protocol, commands from the host computer and responses from the KP inverter take the form of frames.


The data comprising command frames and response frames are explained below.

In the following explanation, an "hex" following a numeric value (for example 02 hex) indicates that the value is a hexadecimal number. A number or letters enclosed in quotation marks (for example "00") is an ASCII character.



STX	This code, 02 hex, indicates the beginning of a communication frame (text). This code must be always set as the first byte. When another STX code is received during reception, the reception starts again from the point where the STX was received.
Node No.	The node address identifies the destination node. <ul style="list-style-type: none"> • The node address can be set to "00" to "99". If you use communication by multiple inverters, set the node address "01" to "31". • There will be no response to a transmission with an invalid node address.
Subaddress	Not used in the KP inverter. Always set the subaddress to "00".
SID (Service ID)	Not used in the KP inverter. Always set the SID to "00".
FINS-mini command and text	The command and required text are placed here. Refer to 2-3 FINS-mini for details.
ETX	This code, 03 hex, indicates the end of text.
BCC	This is the block check character. The BCC is calculated by taking the exclusive OR of all bytes from the node number to the ETX.

BCC Calculation Example




$$BCC = 30 \oplus 30 \oplus 30 \oplus 30 \oplus 30 \oplus 30 \oplus 35 \oplus 30 \oplus 30 \oplus 03 = 36 \text{ hex}$$

⊕ : XOR(exclusive OR) calculation

Note No response will be returned unless the frame contains all elements up to the ETX and BCC

2-2-2 Response Frame Structure



End code	Name	Meaning	Error priority
00	Normal end	The command frame was processed normally without any of the following errors.	None
0F	FINS command error	The specified FINS command could not be executed. Refer to the response code for more details.	8
10	Parity error	The total number of bit which is '1' in response data is not even.	2
11	Framing error	The stop bit is "0".	1
12	Overrun error	Attempted to write new data to the reception register when the reception register was full.	3
13	BCC error	The received BCC did not match the calculated BCC.	5
14	Format error	There was an illegal character in the FINS-mini frame (character other than ASCII 0 to 9 or A to F) or data other than the test data was returned in response to an Echoback Test. There were no SID and FINS-mini. There was no FINS-mini. The FINS-mini MRC and SRC were incorrect.	7
16	Subaddress error	The subaddress was invalid (unsupported). There were no subaddress, SID, and FINS-mini. The subaddress was shorter than 2 characters and there were no SID and FINS-mini.	6
18	Frame length error	The received frame exceeds the specified number of bytes.	4

- An end code is returned for each received command frame addressed to the local node.
- No response will be returned if the message is not complete through the ETX and BCC characters.
- The error priority indicates the priority of the error notification when there were two or more errors.
- The FINS-mini command and text section is not included for end codes other than 00 and 0F.

2-3 FINS-mini

The FINS-mini command text and response text provides the contents of the command and response communications.

2-3-1 PDU Formats

Command Text

The MRC (Main Request Code), SRC (Sub-Request Code), and any required data are transmitted in the command frame.


- **Service Request PDU**



Response Text


The MRC and SRC shown above, MRES (Main Response Code), SRES (Sub-Response Code), and the response data are transmitted in the response frame.

- **Service Response PDU (Normal Response)**



If the specified FINS-mini command could not be executed, service response PDU will contain only the MRC/SRC and MRES/SRES.


- **Service Response PDU (Specified FINS-mini Command Not Executed)**



The MRES and SRES become the response code other than "normal completion".


2-3-2 Variable Areas

The area used for data exchange when communicating with the KP inverter is called the "variable area." The current values are read and various setting data are read and written using the variable area of the KP inverter. Operation commands and Read Controller Attributes do not use the variable area.



2-3-3 Type code (variable type)

The definition of the type code of the variable area does as follows.
For more information, refer to 4-1 Variable Area (Setting Range) List.



Variable type	Support		R/W	Size	Contents
	KP40G	KP□□L			
47	x	x	R/W	Byte	Set Value for setting country
48		x	R	Byte	DC input information
C1	x	x	R/W	Double word	Set value for protective relay
C2	x	x	R	Double word	Standard Measurement
C3	x	x	R	Double word	Standard instruction data
C6		x	R	Double word	Standard Measurement
C8		x	R	Double word	Three Phase Measurement
CA	x	x	R	Double word	Data for PV/grid information
D0	x	x	R	Double word	Error logging

2-3-4 Address

Refer to 4-1 Variable Area (Setting Range) List.

2-3-5 Number of elements

The number of elements is expressed in 2-byte hexadecimal format.
The range for specifying the number of elements differs for each command.
Refer to 2-4 Detailed Description of Services.

2-3-6 List of Services

MRC	SRC	Support		Service name	Processing
		KP40G	KP□□L		
01	01	x	x	Read from variable area	Reads value from variable areas.
01	04		x	Composite read from variable area	Reads composite values from variable areas.
05	01	x	x	Read Controller information	Reads the model and version.
05	03	x	x	Read Controller Attributes	Reads the model number and communications buffer size.
06	01	x	x	Read Controller Status	Reads the operating status.
08	01	x	x	Echoback Test	Performs an echoback test.
30	05	x	x	Operation Command	Performs following operations. - Initialize Error log - Clear the amount of energy for period user set - Setup parameter of Output Power (%) - Setup parameter of Power Factor (PF) - Setup parameter of Reactive Power
41	01	x	x	Read character string area	Reads the character string area.

Note 1 If the Read Start Address is outside of the variable area, the returned read data will be all 0, but the specified number of elements will be returned and the processing will end in "normal completion".

Address	Request	Response
Undefined		00
		Data
Undefined		00

2 If the Read Start Address is within the variable area and the Read End Address (Read Start Address + Number of Elements) is beyond the last variable area address, the read operation will be performed as long as the amount of data up to the last variable area address is within the specified range of the number of elements. The read data beyond the end of the variable area will be all set to 0. (See the following example.)

Address	Request	Response
		Data
Undefined		00
		Data

(4) Response Codes

Response code (MRES+SRES)	Error name	Cause	Error priority
1001	Command too long	The command is too long.	1
1002	Command too short	The command is too short.	2
1101	Area type error	The variable type is incorrect.	3
110B	Response too long	The number of elements exceeds the maximum.	4
1100	Parameter error	The bit position is not 00.	5
0000	Normal completion	No error.	None

(5) Read Data

0 digits, 0 bytes	When the number of elements in the service request PDU is 0000.
2 digits, 1 byte	When the variable type in the service request PDU is "4_".
8 digits, 4 bytes	When the variable type in the service request PDU is "C_" or "D_".

Refer to 4-1 *Variable Area (Setting Range) List* for data details.

"8 digits, 4 bytes" means that when the internal data is 4 bytes, the communications data is 8 bytes.

Example:

Communications data: 0x30 + 0x31 + 0x32 + 0x33 + 0x34 + 0x35 + 0x36 + 0x37

(character expression: 01234567)



Internal data: 0x01234567

2-4-2 Composite read from variable area (KPool only)

This service reads in order the contents of specified addresses in a variable area.
 This command cannot mix variable type C_, variable type 4_, and variable type D_.



Command

● Service Request PDU



Response

● Service Response PDU



(1) Variable Type and Read Start Address

Refer to 4-1 Variable Area (Setting Range) List for information on all types.

(2) Bit Position

Always "00" because there is no bit access.

(3) Number of Elements

Number of elements	Processing
0000	The read operation is not performed (read data is not appended to the service response PDU), and processing ends in "normal completion".
1~33	When the variable type is "4_" The read operation is performed, and processing ends in "normal completion".
1~25	When the variable type is "C_" or "D_" The read operation is performed, and processing ends in "normal completion".

(4) Attention at reading variable area

In case that read address is undefined, read data is [00] (4_ : command) or [00000000](C_, D_:command).

(5) Response Codes


Response code (MRES+SRES)	Error name	Cause	Error priority
1002	Command too short	The command is too short.	1
1101	Area type error	The variable type is incorrect.	2
110B	Response too long	The number of elements exceeds the maximum.	4
1100	Parameter error	The bit position is not 00.	3
0000	Normal completion	No error.	None

2-4-3 Read Controller information

This service reads the Controller's model and version.


Command

● Service Request PDU



Response

● Service Response PDU



(1) Model data

The model number is returned in 20 bytes of ASCII character. If the data is less than 20 bytes long, the remaining bytes will be padded with spaces (20 hex).

The following table shows the model number format.

Model	Model data
KPxxxx-OD-xx	KPxxxx-OD-xx-xx (Space code)

(2) Version data

The version number is returned in 20 bytes of ASCII character. If the data is less than 20 bytes long, the remaining bytes will be padded with spaces (20 hex).

Version	Version data
Vx.xx	x.xx(Space code)

(3) Response Codes


Response code (MRES+SRES)	Error name	Cause	Error priority
1001	Command too long	The command is too long.	1
0000	Normal completion	No error.	None

2-4-4 Read Controller Attributes

This service reads the model number and communications buffer size.


Command

● Service Request PDU



Response

● Service Response PDU



(1) Model data

The model is returned in 10 bytes of ASCII character. If the data is less than 10 bytes long, the remaining bytes will be padded with spaces (20 hex).

Model	Model data
KPxxxx	KPxxxx(Space code)

(2) Buffer Size

The communications buffer size is expressed in 2-byte hexadecimal and is converted to 4-byte ASCII before being displayed.

Model	Buffer Size
KP40G / KP□□L	273bytes (0111)

(3) Response Codes


Response code (MRES+SRES)	Error name	Cause	Error priority
1001	Command too long	The command is too long.	1
0000	Normal completion	No error.	None

2-4-5 Read Controller Status

This service reads the operating status and error status.


Command

● Service Request PDU



Response

● Service Response PDU



(1) Operating status

Operating status				Description	
MSB (Bit)			LSB (Bit)		
			0 0	1)	Stop
			0 1		On grid instruction
			1 0		Reservation
			1 1		Reservation
			0	2)	[KP40G] Excluding turning on both Relay3/4 [KP□□L] Excluding turning on both Relay4/5/6
			1		[KP40G] Turning on both Relay3/4 [KP□□L] Turning on both Relay4/5/6
			0	3)	[KP40G] Excluding turning on both Relay1/2 [KP□□L] Excluding turning on both Relay1/2/3
			1		[KP40G] Turning on both Relay1/2 [KP□□L] Turning on both Relay1/2/3
			0	4)	Gate Block
			1		Excluding while blocking the gate
			0	5)	[KP40G] Excluding while tracing the P-V curve [KP□□L] Excluding turning on Relay N
			1		[KP40G] The P-V curve is being traced [KP□□L] Turning on Relay N
0	0			6)	Reservation

1) Instruction status of the KP inverter.

2) 3) The grid relay ON/OFF status

In KP40G, 4 relays are built into. It indicates whether to have turned on both of relays of a side nears the grid (Relay3/4) among them. Similarly it indicates whether to have turned on the relay of a side near the inside (Relay1/2).

In KP□□L, 6 relays are built into. It indicates whether to have turned on relays of a side nears the grid (Relay4/5/6) among them. Similarly it indicates whether to have turned on the relay of a side near the inside (Relay1/2/3).

- 4) The state to stop the switching of inverter is called a gate block, and the stopped state or the power generation of the output is shown.
- 5) It indicates whether to have turned on the relay of the Neutral line on KP□□L.

(2) Error status

	1(MSB~LSB)				2			
	1	2	3	4	1	2	3	4
KP40G KP□□L	E1-1 OV	E1-2 UV	E1-3 OF	E1-4 UF	E1-5 Islanding Passive	E1-6 Islanding Active	E1-7 OV instantly	E1-8 UV instantly
	3				4			
KP40G KP□□L	E2-1 DC overvoltage	0	E2-3 Ground l fault	E2-4 Insulation resistance fault	E3-1 DC overcurrent	E3-2 AC overcurrent	E3-3 DC current injection	E3-4 Over temperature
	5				6			
KP40G KP□□L	0	0	0	0	E4-1 Abnormality of comparison of measurement	E4-2 Abnormity of efficiency	E4-3 Failure of inverter	E4-4 Abnormal ROM version
	7				8			
KP40G	E4-5 Abnormality of power source	E4-6 Abnormal EEPROM Sum value	E4-7 Failure of EEPROM	E4-8 Abnormality Device setting	E5-1 Failure of relay	E5-2 Communication error between CPUs	0	E5-4 DC/DC undervoltage
KP□□L				0				
	9				10			
KP40G	E5-5 Breaking circuit detecting fault current	E5-6 Failure of inverter (Over- current)	E5-7 Communication error	E5-8 Breaking of circuit detecting leakage circuit	0	0	0	0
KP□□L	0			0	E5-9 Auto test failure			
	11				12			
KP40G KP□□L	0	0	0	0	A2-5 Abnormality of FAN	A2-6 Overvoltage of DD/VD2/VD3	0	E1-0 No Utility
	13				14			
KP40G KP□□L	A1-1 Voltage enhancement control	A1-2 MPPT Control stop	A1-3 Synchronous gap generation	A1-4 DC undervoltage	0	0	A1-7 Output current control	0

(3) Response Codes


Response code (MRES+SRES)	Error name	Cause	Error priority
1001	Command too long	The command is too long.	1
0000	Normal completion	No error.	None

2-4-6 Echoback Test

This service performs an echoback test.


Command

● Service Request PDU



Response

● Service Response PDU



(1) Test Data

Test data is acceptable in the area from 20 to 7E hex in ASCII character.

(2) Response Codes


Response code (MRES+SRES)	Error name	Cause	Error priority
1001	Command too long	The command is too long.	1
0000	Normal completion	No error.	None

2-4-7 Operation Command

This service performs operation command processing to the KP inverter.


Command

● Service Request PDU



Response

● Service Response PDU



(1) Command code and related information

Command code	Command content	Related information
02	Initialize Error log	0000: Error history initialization
06	Change of operation (KP40G, KP100L)	0000: Stop of grid connection operation 0001: Start of grid connection operation 0003: Cancel this operation command
14	Clear Total Periodic Energy that user set	0000
22	Setup parameter of Output Power (%)	0000 to 2710 hex (0.01%) (0.00% to 100.00%) FFFF: Gate block
23	Setup parameter of Power Factor (PF)	F5D8 to 0C80 hex (0.01Deg) (-26.00Deg to 32.00Deg) Standard of AR-N-4105: Accept the command when the Setup mode of Power Factor(PF) is 1.000. Standard of CEI-0: Accept the command when the Setup mode of Reactive Power Control is 1.000. Other than these, return the operation error.
24	Setup parameter of Reactive Power	EC78 to 1388 hex (0.01%) (-50.00 to 50.00%) Standard of CEI-0: Accept the command when the Setup mode of Reactive Power Control is "Percent". Other than this, return the operation error.

Note After command code “06: Change of operation” is sent, if there is no communication more than 60 sec, it becomes internal failure and grid connection is stopped. This is because the KP inverter is controlled by communication safely. If internal failure occurs, send command “06: Change of operation 0003: Cancel this operation command”, then internal failure status is cleared and the KP inverter starts automatically.

Example

To stop the KP inverter, send operation command

3	0	0	5	0	6	0	0	0	0
---	---	---	---	---	---	---	---	---	---

and continue to communicate with the KP inverter such as monitoring of measurement value with interval less than 60sec. To re-start the KP inverter, send operation command

3	0	0	5	0	6	0	0	0	1
---	---	---	---	---	---	---	---	---	---

and continue to communicate with the KP inverter with interval less than 60sec. If there is no communication more than 60sec, the KP inverter is stopped because of failure.

Or to re-start the KP inverter, send operation command

3	0	0	5	0	6	0	0	0	3
---	---	---	---	---	---	---	---	---	---

then the KP inverter start automatically. After this command is sent, it does not need to communicate with the KP inverter continuously.

(2) Response Codes


Response code (MRES+SRES)	Error name	Cause	Error priority
1001	Command too long	The command is too long.	1
1002	Command too short	The command is too short.	2
1100	Parameter error	Command code or related information is not correct.	3
2203	Operation error	Can not process by the operation command. EEP error.	4
0000	Normal completion	No error.	None

2-4-8 Read character string area

This service reads character string area.


Command

● Service Request PDU



Response

● Service Response PDU



(1) Read Data and Read Start Address

Refer to 4-1 Variable Area (Setting Range) List for information on all types.

If data outside the address range is read, read data is not added to service response PDU.

(2) Number of Elements

Number of elements	Processing
0000	The read operation is not performed (read data is not appended to the service response PDU), and processing ends in "normal completion".
0001	The data readout in one character is performed and processing ends in "normal completion".
0002	The data readout in two character is performed and processing ends in "normal completion".
:	
0008	The data readout in 8 character is performed and processing ends in "normal completion".

(3) Response Codes

Response code (MRES+SRES)	Error name	Cause	Error priority
1001	Command too long	The command is too long.	1
1002	Command too short	The command is too short.	2
110B	Response too long	The number of elements exceeds 0008.	3
0000	Normal completion	No error.	None

2-5 Response Code List

Response code (MRES+SRES)	Error name	Cause	Error priority
0000	Normal completion	No error.	None
0401	Unsupported command	The service function for the specified command is not supported.	1
1001	Command too long	The command is too long.	2
1002	Command too short	The command is too short.	3
1101	Area type error	The variable type is incorrect.	4
1003	Number of elements/number of data mismatch	The number of data does not match the number of elements.	5
110B	Response too long	The response exceeds the communications buffer size.	6
1100	Parameter error	<ul style="list-style-type: none"> • The bit position is not 00. • A value that must be 00 was not set to 00. • Incorrect command code or related information in the operation command. • The write data is out of the setting range. 	7
2203	Operation error	Can not process by the operation command. EEPROM error.	8

3

Modbus

3-1	Modbus Communication Specifications	3-2
3-2	Frame Formats	3-3
3-2-1	Command Frame Structure	3-3
3-2-2	Response Frame Structure	3-5
3-3	Function Codes	3-6
3-4	Variable Areas	3-7
3-4-1	Addresses	3-7
3-4-2	Number of Elements	3-7
3-4-3	Communications Data	3-7
3-5	Detailed Description of Services	3-8
3-5-1	Multiple Read from Variable Area	3-8
3-5-2	Single Write to Variable Area	3-9

3-1 Modbus Communication Specifications

Communications Control Method

Programs can be created in the host computer (e.g., a personal computer) to set or monitor parameters in the KP□□L. Therefore the descriptions in this section are from the standpoint of the host computer. For example, "Read/Write" is referred as the host computer reading or writing to the inverter.

Communication Specifications

Interface	RS-485
Transmission path connections	Multipoint
Communications	2-wire system half duplex
Baud rate	4800 / 9600 / *19200bps
Synchronization	Start-stop synchronization
Transmitted code	RTU (Binary code)
Data bit length	8 bits
Stop bit length	*1 bit / 2bits
Error detection	Parity check (Odd / * Even / None) CRC-16 (Cyclical Redundancy Check)
Flow control	None
Retry function	None
Minimum interval from when command is sent to when next command is issued (the time recognize the end of command)	3.5Char or more 19200bps : about 2ms or more (11bit/Char) 9600bps : about 4ms or more (11bit/Char)
Minimum interval from when response is received to when next command is issued	3.5Char or more 19200bps : about 2ms or more (11bit/Char) 9600bps : about 4ms or more (11bit/Char)

* default


3-2 Frame Formats

Modbus is a communications control method that conforms to the RTU Mode of the Modbus protocol specifications (PI-MBUS-300 Rev. J) of Modicon Inc.

The host computer sends a command frame, and the KP□□L sends a response frame based on the content of the command frame. One response frame is sent in response to one command frame.

3-2-1 Command Frame Structure

In the following explanation, an "hex" following a numeric value (for example 02 hex) indicates that the value is a hexadecimal number. A number or letters enclosed in quotation marks (for example "00") is an ASCII character. In RTU Mode, each frame begins and ends with a silent time interval that is at least 3.5 characters long.



	Silent interval at least 3.5 characters long.
Slave address	Specify the node number of the KP inverter between 00 hex and 63 hex (0 to 99). When broadcasting to all nodes, specify 00 hex. Responses are not returned for broadcasts.
Function code	The function code specifies the command type from the host computer. The code is set in hexadecimal and is 1 byte long. For more information, refer to <i>4-1 Variable Area (Setting Range) List</i>
Data	The text of command based on the function code. Specifies variable addresses and the values for set values in hexadecimal.
CRC-16	Cyclical Redundancy Check These two bytes store check code calculated from the slave address to the end of the data in hexadecimal.
	Silent interval at least 3.5 characters long.

Note The maximum size of a Modbus RTU frame is 256 bytes.


Example of CRC-16 Calculation

A message is processed 1 byte at a time in a 16-bit processing register called the CRC register.

- 1** A default value of FFFF hex is set in the CRC register.
- 2** An XOR is taken of the contents of the CRC register and the first byte of the message, and the result is returned to the CRC register.
- 3** The contents of the CRC register is shifted 1 bit to the right, and 0 is placed in the MSB.
- 4** If the bit shifted from the LSB is 0, step 3 is repeated (i.e., the contents of the register is shifted 1 more bit).
If the bit shifted from the LSB is 1, an XOR is taken of the contents of the CRC register and A001 hex, and the result is returned to the CRC register.
- 5** Steps 3 and 4 are repeated until the contents of the register have been shifted 8 bits to the right.
- 6** If the end of the message has not been reached, an XOR is taken of the next byte of the message and the CRC register, the result is returned to the CRC register, and the procedure is repeated from step 3.
- 7** The result (the value in the CRC register) is placed in the lower byte of the message.


Example of Appending the Result

If the calculated CRC value is 1234 hex, this is appended as follows to the command frame.




3-2-2 Response Frame Structure

Normal Response Frames



Error Response Frames



Slave address	The node number that was specified in the command frame is returned here. This is the node number of the responding KP inverter.
Function code	The function code that was received is returned here. In an error response frame, 80 hex is added to the value to indicate that this is an error response. Example: Received function code = 03 hex Function code in error response frame = 83 hex
Error code	An end code that indicates the error.
CRC-16	Cyclical Redundancy Check These two bytes are a check code calculated from the slave address through the end of the data in hexadecimal.

No Response

In the following cases, the received command is not processed and a response is not returned. A timeout will occur at the host device.


- The slave address in the received command is different from the communications unit number set in the KP inverter.
- A parity error, framing error, or overrun error occurred due to a transfer error or other error.
- A CRC-16 code error occurred in the received command frame.
- A time interval greater than 3.5 characters occurred between data while receiving a command frame. In the following case, the command is processed, but a response is not returned.
- Broadcast transmission (Slave address: 00hex)

3-3 Function Codes

Function code	Name	Description
03 (03 hex)	Multiple Read from Variable Area	Reads from a variable area. Multiple variables that are consecutive can be read.
06 (06 hex)	Single Write to Variable Area	Writes to a variable area or an operation command. Broadcasting is possible.
08 (08 hex)	Echoback Test	Performs an echoback test.

3-4 Variable Areas

The area used for data exchange when communicating with the KP□□L is called the "variable area." The current values are read and various setting data are read/written using the variable area of the KP□□L.



3-4-1 Addresses

Refer to 4-1 Variable Area (Setting Range) List for parameter addresses. Parameters with the following variable types can be used with the Modbus protocol.

3-4-2 Number of Elements

The number of elements is expressed in 2-byte hexadecimal format.
The range for specifying the number of elements differs for each command.
Refer to 4-1 Variable Area (Setting Range) List.

3-4-3 Communications Data

Setting (monitor) value	Communications data (See note.)	Negative values	Decimal point
Hexadecimal	2 bytes	2's complement	The decimal point is removed and the result is converted to hexadecimal. Example: 105.0 → 1050 → 041A


Note Refer to 4-1 Variable Area (Setting Range) List.

3-5 Detailed Description of Services

3-5-1 Multiple Read from Variable Area


This service reads data from the variable area.

Command




Response

[Normal response]



[Abnormal response]



(1) Read Start Address

Refer to 4-1 Variable Area (Setting Range) List.

Same data as Read Controller information (2-4-3 Read Controller information) and Read Controller Status (2-4-5 Read Controller Status) in CompoWay/F can be read by this service.

Refer to 4-1 Variable Area (Setting Range) List in detail to read Controller information and Controller status.

(2) No. of Elements

Specify the number of elements to read. The specification range is from 0001 to 007D hex (1 to 125 elements).

(3) Byte Count

The number of bytes of data that was read is returned.


(4) Response Codes

Function code	Error code	Error name	Cause
83 hex	02 hex	Variable address error	The read start address is not correct.
	03 hex	Variable data error	<ul style="list-style-type: none"> The command is too long. The command is not long enough. The number of elements has exceeded the maximum limit.
03 hex	--	Normal completion	The service was processed normally.

3-5-2 Single Write to Variable Area


This service either writes data to the variable area or executes the operation commands.

Command




Response

[Normal response]



[Abnormal response]



(1) Write Start Address

Set the write start address to FFFF hex when executing an operation command. When writing to the variable area, refer to 4-1 Variable Area (Setting Range) List.

(2) Write Data

When executing an operation command, place the write data as follows.

Upper byte: command code

Lower byte: related information

Command content	Command code (upper byte)	Related information (lower byte)
Initialize Error log	0x02	0x00
Clear Total Periodic Energy that user set	0x14	0x00

(3) Response Codes

Function code	Error code	Error name	Cause
86 hex	02 hex	Variable address error	The write start address is not correct.
	03 hex	Variable data error	<ul style="list-style-type: none"> The command is too long. The command is not long enough.
06 hex	--	Normal completion	The service was processed normally.



Communications Data

4-1 Variable Area (Setting Range) List 4-2

4-1 Variable Area (Setting Range) List

The following table indicates the variable areas. Items expressed in hexadecimal in the “Content explanation” column are the setting range for CompoWay/F or Modbus communications. The values in parentheses are the actual setting range.

Address		Modbus	Variable identifier	Content explanation	
CompoWay/F				KP□□L	KP40G
Type Code	Address			(CompoWay/F & Modbus)	(CompoWay/F)
47 Set Value for setting country Read/Write	0000	0A00 (upper)	Country setting	0x00: [GER] Germany 0x01: [FRA] France 0x02: [GRE] Greece 0x03: [CZE] Czech Republic 0x04: [DEN] Denmark 0x05: [TUR] Turkey 0x06: [RSA] Republic of South Africa 0x07: [ESP] Spain 0x08: [POR] Portugal 0x09: [ITA] Italy	KP40G-OD-1: 0x00: none 0x01: Netherlands 0x02: Italy 0x03: Spain 0x04-FF: none KP40G-OD-2: 0x00: none 0x01: Germany(with ENS) 0x02: Germany(without ENS) 0x03: Austria(with ENS) 0x04: Austria(without ENS) 0x05: none 0x06: Switzerland(without ENS) 0x07-FF: reserved
	0001	0A00 (lower)	Reserved	Reserved	Reserved
48 Set each model Read Only	0000	0B00 (upper)	The number of DC input	03 : 3 inputs	---
	0001	0B00 (lower)	Reserved	Reserved	---
C1 Protective Relay Read/Write	0000	5500	Setting value of overvoltage (OV)	00000000 to 000005DC hex (0.2V)	00000000 to 000005DC hex (0.2V)
		5501		0 to 300.0V)	0 to 300.0V)
	0001	5502	Setting value of undervoltage (UV)	00000000 to 000005DC hex (0.2V)	00000000 to 000005DC hex (0.2V)
		5503		0 to 300.0V)	0 to 300.0V)
	0002	5504	Setting value of overfrequency (OF)	50Hz: 00001392 to 0000157C hex (0.01Hz)	50Hz:000013BA to 00001450 hex (50.50 to 52.00Hz)
		5505		50.10 to 55.00Hz) 60Hz: 0000177A to 00001964 hex (0.01Hz)	60Hz:000017A2 to 00001838 hex (60.50Hz to 62.00Hz)
	0003	5506	Setting value of underfrequency (UF)	50Hz: 0000125C to 0000137E hex (0.01Hz)	50Hz:000012C0 to 00001356 hex (48.00 to 49.50Hz)
		5507		47.00 to 49.90Hz) 60Hz: 00001644 to 00001766 hex (0.01Hz)	60Hz:000016A8 to 0000173E hex (58.00 to 59.50Hz)
	0009	5512/5513	Setting value of exchange voltage rising	00000000 to 000005DC hex (0.2V)	---
0032	5564/5565	start-up condition: setting value of overfrequency	0000138D to 000013EC hex (0.01Hz)	---	
0033	5566/5567	start-up condition: setting value of underfrequency	00001324 to 00001383 hex (0.01Hz)	---	

Address			Variable identifier	Content explanation	
CompoWay/F		Modbus		KP□□L (CompoWay/F & Modbus)	KP40G (CompoWay/F)
Type Code	Address				
C2 Standard Measurement	0000	5A00	PV-input voltage[1] (DC voltage[1])	00000000 to 0000FFFF hex (0.0 to 6553.5V)	00000000 to 0000FFFF hex (0.0 to 6553.5V)
		5A01			
Read Only	0001	5A02	Current from PV-panels[1] (Direct current[1])	FFFF8000 to 00007FFF hex (-327.68 to 327.67A)	FFFF8001 to 00007FFF hex (-327.67 to 327.67A)
		5A03			
	0002	5A04	PV-input power[1] (DC power[1])	FFFF0000 to 0000FFFF hex (-65536 to 65535W)	FFFF0001 to 0000FFFF hex (-65535 to 65535W)
		5A05			
	0004	5A08	Utility voltage [L1]	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)
		5A09			
	0006	5A0C	Grid frequency	00000000 to 0000FFFF hex (0 to 655.35Hz)	00000000 to 0000FFFF hex (0 to 655.35Hz)
		5A0D			
	0007	5A0E	Output voltage[L1]	00000000 to 0000FFFF hex (0 to 6553.5V)	---
		5A0F			
	0008	5A10	Output current[L1]	00000000 to 0000FFFF hex (0 to 655.35A)	00000000 to 0000FFFF hex (0 to 655.35A)
		5A11			
	0009	5A12	Output power (without software filter)	FFFF8000 to 00007FFF hex (-32768 to 32767W)	---
		5A13			
	000A	5A14	Output power for display (with software filter)	FFFF8000 to 00007FFF hex (-32768 to 32767W)	FFFF0001-0000FFFF hex (-65535 to 65535W)
		5A15			
	0010	5A20	TNS : Total number start-up's	00000000 to 0000FFFF hex (0 to 65535times)	00000000 to 0000FFFF hex (0 to 65535times)
		5A21			
	0100	5C00	Recovery time	80000000 to 7FFFFFFF hex (-214748364.8 to 214748364.7s)	---
		5C01			
C3 Standard instruction data	0000	6000	Total energy after installing the inverter (Amount of operation)	00000000 to 3B9AC9FF hex (0 to 999999999W•h)	00000000 to 3B9AC9FF hex (0 to 999999999W•h)
		6001			
Read Only	0001	6002	The amount of energy for period user set	00000000 to 3B9AC9FF hex (0 to 999999999W•h)	00000000 to 3B9AC9FF hex (0 to 999999999W•h)
		6003			
	0002	6004	Total operating hours	00000000 to FFFFFFFF hex (0 to 4294967295s)	00000000 to FFFFFFFF hex (0 to 4294967295s)
		6005			
C6 Standard Measurement	0006	700C/700 D	Inverter Temperature (°C)	0x00000000 to 0x0000FFFF hex (0.01°C) (0 to 655.35°C)	---
Read Only					

Address			Variable identifier	Content explanation	
CompoWay/F		Modbus		KP□□L	KP40G
Type Code	Address			(CompoWay/F & Modbus)	(CompoWay/F)
C8 Three Phase Measurement	0002	7A04	Total PV-input power	FFFF0000 to 0000FFFF hex (-65536 to 65535W)	---
		7A05			
Read Only	0004	7A08	Utility voltage [L1]	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)	---
		7A09			
	0005	7A0A	Utility voltage [L2]	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)	---
		7A0B			
	0006	7A0C	Utility voltage [L3]	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)	---
		7A0D			
	0007	7A0E	Grid frequency	00000000 to 0000FFFF hex (0 to 655.35Hz)	---
		7A0F			
	0008	7A10	Output voltage[L1]	00000000 to 0000FFFF hex (0.1V) (0 to 6553.5V)	---
		7A11			
	0009	7A12	Output voltage[L2]	00000000 to 0000FFFF hex (0.1V) (0 to 6553.5V)	---
		7A13			
	000A	7A14	Output voltage[L3]	00000000 to 0000FFFF hex (0.1V) (0 to 6553.5V)	---
		7A15			
	000B	7A16	Output current[L1]	00000000 to 0000FFFF hex (0 to 655.35A)	---
		7A17			
	000C	7A18	Output current[L2]	00000000 to 0000FFFF hex (0 to 655.35A)	---
		7A19			
	000D	7A1A	Output current[L3]	00000000 to 0000FFFF hex (0 to 655.35A)	---
		7A1B			
	000E	7A1C	Output power (without software filter)	FFFF8000 to 00007FFF hex (-32768 to 32767W)	---
		7A1D			
	000F	7A1E	Output power for display (with software filter)	FFFF8000 to 00007FFF hex (-32768 to 32767W)	---
		7A1F			
	0015	7A2A	Utility voltage [L1-L2]	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)	---
		7A2B			
	0016	7A2C	Utility voltage [L2-L3]	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)	---
		7A2D			
	0017	7A2E	Utility voltage [L3-L1]	00000000 to 0000FFFF hex (0.2V) (0 to 13107V)	---
		7A2F			
	0100	7C00	PV-input voltage[1] (DC voltage[1])	00000000 to 0000FFFF hex (0.0 to 6553.5V)	---
		7C01			
	0101	7C02	Current from PV-panels[1] (Direct current[1])	00000000 to 0000FFFF hex (0.00 to 655.35A)	---
		7C03			
	0102	7C04	PV-input power[1] (DC power[1])	FFFF0000 to 0000FFFF hex (-65536W to 65535W)	---
		7C05			
	0200	7E00	PV-input voltage[2] (DC voltage[2])	00000000 to 0000FFFF hex (0.0 to 6553.5V)	---
		7E01			
	0201	7E02	Current from PV-panels[2] (Direct current[2])	00000000 to 0000FFFF hex (0.00 to 655.35A)	---
		7E03			

Address			Variable identifier	Content explanation	
CompoWay/F		Modbus		KP□□L (CompoWay/F & Modbus)	KP40G (CompoWay/F)
Type Code	Address				
C8 Three Phase Measurement Read only	0202	7E04	PV-input power[2] (DC power[2])	FFFF0000 to 0000FFFF hex (-65536W to 65535W)	---
		7E05			
	0300	8000	PV-input voltage[3] (DC voltage[3])	00000000 to 0000FFFF hex (0.0 to 6553.5V)	---
		8001			
	0301	8002	Current from PV-panels[3] (Direct current[3])	00000000 to 0000FFFF hex (0.00 to 655.35A)	---
		8003			
	0302	8004	PV-input power[3] (DC power[3])	FFFF0000 to 0000FFFF hex (-65536W to 65535W)	---
		8005			
CA Data for ENS Read only	0004	9508	Riso (Insulation Resistance)	00000000 to 0000FFFF hex (0.1kohm) (0 to 6553.5kohm)	00000000 to 0000FFFF hex (0.1kohm) (0 to 6553.5kohm)
		9509			
	0007	950E	Zac (Line Impedance)	---	00000000 to 0000CCD hex (0.01ohm) (0 to 32.77ohm)
		950F			
D0 Error logging Read Only	0000	C000-C003	Error messages memory Latest error logging	Four high rank bytes are 0000 Four subordinate position bytes are abnormal history data.	Four high rank bytes are 0000 Four subordinate position bytes are abnormal history data.
	0001	C004-C007	The previous error log from 1 the latest	(example) When an abnormal history data is "E4-4" "0000E4-4"	(example) When an abnormal history data is "E4-4" "0000E4-4"
	0002	C008-C00B	The previous error log from 2 the latest		
	:	:	:		
	0030	C0C0-C0C3	The previous error log from 48 the latest		
	0031	C0C4-C0C7	The previous error log from 49 the latest		
Character string data Read Only	0000	Not Supported	Serial number	Serial number 16 bytes	Serial number 16 bytes
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		
			Serial number		

Address			Variable identifier	Content explanation	
CompoWay/F		Modbus		KP□□L (CompoWay/F & Modbus)	KP40G (CompoWay/F)
Type Code	Address				
Modbus read only	Not Supported	FFE0	For read controller information	Model Name 20 bytes	---
		FFE1	Data is same as Model data (20 bytes) by Controller information in CompoWay/F (MRC="05", SRC="01")		
		FFE2			
		FFE3			
		FFE4			
		FFE5			
		FFE6			
		FFE7			
		FFE8			
		FFE9			
		FFEA	For read controller information	Inverter's Firmware Version 20 bytes	---
		FFEB	Data is same as Version data (20 bytes) by Controller information in CompoWay/F (MRC="05", SRC="01")		
		FFEC			
		FFED			
		FFEE			
		FFEF			
		FFF0			
		FFF1			
		FFF2			
FFF3					

Address			Variable identifier	Content explanation	
CompoWay/F		Modbus		KP□□L (CompoWay/F & Modbus)	KP40G (CompoWay/F)
Type Code	Address				
Modbus read only	Not Supported	FFFB	For read controller status	Operating status & Error status(1-2)	---
		FFFC	Data is same as status of drive and error status (total 16 bytes) by Controller status in CompoWay/F (MRC="06", SRC="01")	Error status(3-6)	
		FFFD		Error status(7-10)	
		FFFE		Error status(11-14)	
Modbus write only	Not Supported	FFFF		For operation command	command code(upper)
			refer Modbus command	related information(lower)	

